

LISTA DE APLICACIONES - BUYERS GUIDE

1.9 D (XUD9)	Diesel	FWD	1905	51	69	04.93-05.99	*
1.9 D (D8A (XUD9TE))	Diesel	FWD	1905	68	92	01.93-12.97	*
1.9 D (D8A (XUD9TE))	Diesel	FWD	1905	68	92	01.93-12.97	*
306 (7D, N3, N5) 01.94-04.02				Cabrío (Compact car-C Segment)			
1.8 (L6A (XU7JP))	Gasolina	FWD	1761	74	101	03.94-04.02	*
1.8 (L6A (XU7JP))	Gasolina	FWD	1761	74	101	03.94-04.02	*
1.8 (LFZ (XU7JP))	Gasolina	FWD	1761	74	101	03.94-04.02	*
1.8 (LFZ (XU7JP))	Gasolina	FWD	1761	74	101	03.94-04.02	*
306 (7B, N3, N5) 04.93-10.03				Sedán (Compact car-C Segment)			
1.1 (HDZ (TU1M))	Gasolina	FWD	1124	44	60	06.94-05.01	*
1.1 (HDZ (TU1M))	Gasolina	FWD	1124	44	60	06.94-05.01	*
1.4 SL (KDX (TU3MC))	Gasolina	FWD	1360	55	75	06.94-05.01	*
1.4 SL (KDX (TU3MC))	Gasolina	FWD	1360	55	75	06.94-05.01	*
1.4 SL (KFW (TU3JP))	Gasolina	FWD	1360	55	75	06.94-05.01	*
1.4 SL (KFW (TU3JP))	Gasolina	FWD	1360	55	75	06.94-05.01	*
1.4 SL (KFX (TU3JP))	Gasolina	FWD	1360	55	75	06.94-05.01	*
1.4 SL (KFX (TU3JP))	Gasolina	FWD	1360	55	75	06.94-05.01	*
1.4 SL (KFX (TU3JP))	Gasolina	FWD	1360	55	75	06.94-05.01	*
1.6 SR (NFZ (TU5JP))	Gasolina	FWD	1587	65	89	06.94-10.00	*
1.6 SR (NFZ (TU5JP))	Gasolina	FWD	1587	65	89	06.94-10.00	*
1.8 ST (LFZ (XU7JP))	Gasolina	FWD	1761	74	101	06.94-05.01	*
1.8 ST (LFZ (XU7JP))	Gasolina	FWD	1761	74	101	06.94-05.01	*
1.9 D (WJY (DW8B))	Diesel	FWD	1868	51	69	09.98-05.01	*
1.9 D (WJY (DW8B))	Diesel	FWD	1868	51	69	09.98-05.01	*
1.9 D (WJZ (DW8))	Diesel	FWD	1868	51	69	09.98-05.01	*
1.9 D (WJZ (DW8))	Diesel	FWD	1868	51	69	09.98-05.01	*
1.9 SLD (DJZ (XUD9A))	Diesel	FWD	1905	47	64	06.94-05.01	*
1.9 SLD (DJZ (XUD9A))	Diesel	FWD	1905	47	64	06.94-05.01	*
1.9 SLD (DJY (XUD9A))	Diesel	FWD	1905	50	68	06.94-05.01	*
1.9 SLD (DJY (XUD9A))	Diesel	FWD	1905	50	68	06.94-05.01	*
1.9 STD (D9B (XUD9A))	Diesel	FWD	1905	51	69	02.94-10.95	*
1.9 STD (D9B (XUD9A))	Diesel	FWD	1905	51	69	02.94-10.95	*
1.9 STD (XUD9)	Diesel	FWD	1905	51	69	02.94-10.95	*
1.9 STD (XUD9)	Diesel	FWD	1905	51	69	02.94-10.95	*
1.9 D (DHV (XUD9BSD))	Diesel	FWD	1905	55	75	03.98-05.01	*
1.9 D (DHV (XUD9BSD))	Diesel	FWD	1905	55	75	03.98-05.01	*
1.9 SRDT (DHY (XUD9TE))	Diesel	FWD	1905	66	90	06.94-05.01	*
1.9 SRDT (DHY (XUD9TE))	Diesel	FWD	1905	66	90	06.94-05.01	*
1.9 D (D8A (XUD9TE))	Diesel	FWD	1905	68	92	02.94-12.97	*
1.9 D (D8A (XUD9TE))	Diesel	FWD	1905	68	92	02.94-12.97	*