


# LISTA DE APLICACIONES - BUYERS GUIDE

## 3R18025624

Weight: 18.035



## 3R18025624



Trw

162.1x66.9x18.9

Ø280x28x48

**WVA**

24595

24608

Sin Filas



Trac.	CC	Kw	CV	
				Front / Rear

### CITROËN

#### JUMPY II / DISPATCH 01.07-

**[CAMBIADO]:Furgón (LCVs-N1 Segment)**

1.6 HDi 90 16V (9HU (DV6UTED4))	Diesel	FWD	1560	66	90	01.07-03.16	*
1.6 HDi 90 16V (9HU (DV6UTED4))	Diesel	FWD	1560	66	90	01.07-03.16	*
1.6 HDi 90 8V (9HH (DV6DUM))	Diesel	FWD	1560	66	90	01.07-03.16	*
1.6 HDi 90 8V (9HH (DV6DUM))	Diesel	FWD	1560	66	90	01.07-03.16	*
1.6 HDi 90 8V (9HM (DV6UC))	Diesel	FWD	1560	66	90	01.07-03.16	*
1.6 HDi 90 8V (9HM (DV6UC))	Diesel	FWD	1560	66	90	01.07-03.16	*

#### JUMPY II / DISPATCH (VF7) 01.07-

**Bus (Minibus-M2-Segment)**

1.6 HDi 90 16V (9HU (DV6UTED4))	Diesel	FWD	1560	66	90	01.07-03.16	*
1.6 HDi 90 16V (9HU (DV6UTED4))	Diesel	FWD	1560	66	90	01.07-03.16	*
1.6 HDi 90 8V (9HH (DV6DUM))	Diesel	FWD	1560	66	90	01.07-03.16	*
1.6 HDi 90 8V (9HH (DV6DUM))	Diesel	FWD	1560	66	90	01.07-03.16	*
1.6 HDi 90 8V (9HM (DV6UC))	Diesel	FWD	1560	66	90	01.07-03.16	*
1.6 HDi 90 8V (9HM (DV6UC))	Diesel	FWD	1560	66	90	01.07-03.16	*

### FIAT

#### SCUDO II (270\_, 272\_) 01.07-

**[CAMBIADO]:Furgón (LCVs-N1 Segment)**

1.6 D Multijet (9HU)	Diesel	FWD	1560	66	90	01.07-03.16	*
1.6 D Multijet (9HU)	Diesel	FWD	1560	66	90	01.07-03.16	*

#### SCUDO II (270\_, 272\_) 01.07-

**Bus (Minibus-M2-Segment)**

1.6 D Multijet (9HU)	Diesel	FWD	1560	66	90	01.07-03.16	*
1.6 D Multijet (9HU)	Diesel	FWD	1560	66	90	01.07-03.16	*

# LISTA DE APLICACIONES - BUYERS GUIDE

SCUDO II (270_, 272_) 01.07-					Caja/Chasis (LCVs-N1 Segment)			
1.6 D Multijet (9HU)	Diesel	FWD	1560	66	90	01.07-03.16	*	
1.6 D Multijet (9HU)	Diesel	FWD	1560	66	90	01.07-03.16	*	
PEUGEOT								
EXPERT II (VF3A_, VF3U_, VF3X_) 01.07-					[CAMBIADO]:Furgón (LCVs-N1 Segment)			
1.6 HDi 90 16V (9HU (DV6UTED4))	Diesel	FWD	1560	66	90	01.07-	*	
1.6 HDi 90 16V (9HU (DV6UTED4))	Diesel	FWD	1560	66	90	01.07-	*	
1.6 HDi 90 8V (9HH (DV6DUM))	Diesel	FWD	1560	66	90	01.07-	*	
1.6 HDi 90 8V (9HH (DV6DUM))	Diesel	FWD	1560	66	90	01.07-	*	
1.6 HDi 90 8V (9HM (DV6UC))	Diesel	FWD	1560	66	90	01.07-	*	
1.6 HDi 90 8V (9HM (DV6UC))	Diesel	FWD	1560	66	90	01.07-	*	
EXPERT II 01.07-					Caja/Chasis (LCVs-N1 Segment)			
1.6 HDi 90 16V (9HU (DV6UTED4))	Diesel	FWD	1560	66	90	01.07-	*	
1.6 HDi 90 16V (9HU (DV6UTED4))	Diesel	FWD	1560	66	90	01.07-	*	
EXPERT II Tepee (VF3X_) 01.07-					Bus (Minibus-M2-Segment)			
1.6 HDi 90 16V (9HU (DV6UTED4))	Diesel	FWD	1560	66	90	01.07-03.16	*	
1.6 HDi 90 16V (9HU (DV6UTED4))	Diesel	FWD	1560	66	90	01.07-03.16	*	
1.6 HDi 90 8V (9HH (DV6DUM))	Diesel	FWD	1560	66	90	01.07-03.16	*	
1.6 HDi 90 8V (9HH (DV6DUM))	Diesel	FWD	1560	66	90	01.07-03.16	*	
1.6 HDi 90 8V (9HM (DV6UC))	Diesel	FWD	1560	66	90	01.07-03.16	*	
1.6 HDi 90 8V (9HM (DV6UC))	Diesel	FWD	1560	66	90	01.07-03.16	*	
TOYOTA								
PROACE (MDX_) 06.13-03.16					[CAMBIADO]:Furgón (LCVs-N1 Segment)			
1.6 D (MDX9) (3WZ-TV)	Diesel	FWD	1560	66	90	06.13-03.16	*	
1.6 D (MDX9) (3WZ-TV)	Diesel	FWD	1560	66	90	06.13-03.16	*	
2.0 D (MDX3) (4WZ-FTW)	Diesel	FWD	1997	94	128	06.13-03.16	*	
2.0 D (MDX3) (4WZ-FTW)	Diesel	FWD	1997	94	128	06.13-03.16	*	
2.0 D (MDX6) (4WZ-FHV)	Diesel	FWD	1997	120	163	06.13-03.16	*	
2.0 D (MDX6) (4WZ-FHV)	Diesel	FWD	1997	120	163	06.13-03.16	*	