

# LISTA DE APLICACIONES - BUYERS GUIDE

## RB1394




8 424073 129970

Qty: 300

Weight: 1.055

O.E.M.	MAKE
55810-64G00	SUZUKI
55810-64G01	SUZUKI
55810-64G10	SUZUKI
55810-64G11	SUZUKI



## RB1394



90R-01101/331



Sumitomo

108.6x47.9x15

WVA

23795

23796

23797

24168

Sin Filas



Trac.

CC

Kw

CV



Front / Rear

### SUZUKI

#### BALENO (EG) 03.95-05.02

[CAMBIADO]:Fastback (Supermini car-B Segment)

1.3	Gasolina	FWD	1298	48	65	04.96-10.97	*
1.3 (SY413) (G13BA)	Gasolina	FWD	1298	52	71	09.96-05.02	*
1.3 i 16V (SY413) (G13BB)	Gasolina	FWD	1298	63	85	07.95-05.02	*
1.6 i 16V (SY416) (G16B)	Gasolina	FWD	1590	72	98	07.95-05.02	*
1.6 i 16V 4x4 (SY416) (G16B)	Gasolina	4WD	1590	72	98	07.95-05.02	*
1.8 GTX (SY418) (J18A)	Gasolina	FWD	1839	89	121	03.96-05.02	*
1.9 TD (SY419) (DHW (XUD9SD))	Diesel	FWD	1905	55	75	04.98-05.02	*

#### BALENO / ESTEEM (EG) 04.95-04.05

[CAMBIADO]:Break (Supermini car-B Segment)

1.3 16V (SY413) (G13BB)	Gasolina	FWD	1298	63	86	03.97-05.02	*
1.6 i 16V (SY416) (G16B)	Gasolina	FWD	1590	72	98	08.96-05.02	*
1.6 i 16V 4x4 (SY416) (G16B)	Gasolina	4WD	1590	72	98	08.96-05.02	*
1.6 i 16V (SY416) (G16B)	Gasolina	FWD	1590	73	99	08.96-05.02	*
1.6 i 16V 4x4 (SY416) (G16B)	Gasolina	4WD	1590	73	99	08.96-05.02	*
1.8 i 16V (SY418) (J18A)	Gasolina	FWD	1839	89	121	08.96-05.02	*
1.9 TD (SY419) (DHW (XUD9BSD))	Diesel	FWD	1905	55	75	04.98-05.02	*
1.9 TD (SY419) (DHW (XUD9SD))	Diesel	FWD	1905	55	75	04.98-05.02	*

#### BALENO / ESTEEM (EG) 03.95-12.09

Sedán (Supermini car-B Segment)

1.3 (SY413) (G13BA)	Gasolina	FWD	1298	52	71	09.96-05.02	*
1.3 i 16V (SY413) (G13BB)	Gasolina	FWD	1298	63	85	07.95-05.02	*
1.6 i 16V (SY416) (G16B)	Gasolina	FWD	1590	72	98	07.95-05.02	*
1.6 i 16V 4x4 (SY416) (G16B)	Gasolina	4WD	1590	72	98	07.95-05.02	*
1.8 GTX (SY418) (J18A)	Gasolina	FWD	1839	89	121	03.96-05.02	*

## LISTA DE APLICACIONES - BUYERS GUIDE

1.9 TD (SY419) (DHV (XUD9BSD))	Diesel	FWD	1905	55	75	04.98-05.02	*
1.9 TD (SY419) (DHW (XUD9SD))	Diesel	FWD	1905	55	75	04.98-05.02	*